

1/29






FIG. 1





4/29

FROM USER LOGIN MODE,  
UNLOAD SPECIMEN MODE,  
OR MANUAL REVIEW




FIG. 3

5/29




FIG. 4



7/29




FIG. 5B




FIG. 5C

8/29




FIG. 5D




FIG. 6



9/29




FIG. 5E




FIG. 7




FIG. 8

FIG. 10

FIG. 10

12/29




FIG. 11

20



14/29




FIG. 14




FIG. 15A




FIG. 15B

15/29





FIG. 16

16/29



NOTICE: DOES NOT  
SHOW INTERMEDIATE  
CONNECTIONS OR  
ACTUAL ROUTING  
OF CABLES.

FIG. 17



17/29




FIG. 18A




FIG. 18B

18/29




FIG. 19

19/29







FIG. 20




FIG. 21


21/29





23/29





**FIG. 27**






FIG. 28




FIG. 29

27/29





FIG. 30






FIG. 32